

Installing strap buttons on an Autoharp

The screw holes for the strap button screws must be pre-drilled. Be sure the bit you use is as large as the shank of the screw, leaving only the threads of the screw to hold in the wood.

Our buttons are best drilled with a 3/32" drill bit.

Put the screw through the button and hold the bit up to the exposed part of the screw (the part that will sink into the 'harp) and mark the depth of the hole on the bit with masking tape.

Strap buttons may be installed in a variety of places, they are best placed on the edge of the autoharp. Here are the most common:

